

# Installation Manual & Cutout-Details



Install appropriate cautionary marking or warning labels




To maintain the environmental rating of the enclosure install only listed or recognized disconnect appropriate environmental rating

Install according to disconnect manufactures installation instructions



The disconnecting means supplying the enclosure is interlocked mechanically to the enclosure door

Disconnect handle not supplied by SCE

Use of a key or tool is necessary for access



Shipped loose with enclosure	
Part #	Description
118661	EXD mounting hardware bolt pack
117811	Strip Gasket




## Gasket Installation:


Starting at the bottom of the external disconnect, install the gasket (item 6) around the side of the enclosure between the edge and the holes. Edge the end of the gasket up to the start point to ensure no water can travel through.

### Optional Cover Plates




Identifier	Description
1	128669 Cover Plate
2	133662 Cover Plate
3	10-32 Nuts




Showing front of enclosure removing front  
Key components highlighted red



Zoomed partial view  
Dotted lines represent connected pem/hole/nuts



# SCE-EXD12



# SCE-EXD18

