

CENTER CHANNELS



ENCLOSURE EXTERNAL VIEW

SEALANT BEAD APPLIED TO JUST THE INSIDE LEFT AND RIGHT SIDE OF GASKET SURFACES TOP AND BOTTOM.



-APPLY SEALANT TO JUST THE INSIDE LEFT AND RIGHT SIDES OF THE GASKET SURFACE FOR ADDED CONEALANT.

-ALIGN THE GASKET WITH THE CENTER CHANNEL BRACKETS, AND INSTALL CENTER CHANNEL AS SHOWN.

-SECURE ALL FASTENERS TO 60 TO 80 INCH LBS.



ENCLOSURE INTERNAL VIEW

SEALANT BEAD APPLIED TO JUST THE INSIDE LEFT AND RIGHT SIDE OF GASKET SURFACES TOP AND BOTTOM.

