

# Cutler-Hammer Flange Mounted, Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated.

The D1 Cutout detail is the standard cutout in all Stock SCE enclosures with the exception of:

Letter U at the end of the part number enclosure has Universal disconnect cutout.

Part#	Cutout	With Adaptor SCE-UA400V	With Adaptor SCE-UAV
SCE-72XM3418U	D7	D2	D1
SCE-80XM4018U	D7	D2	D1
SCE-72XM6618U	D7	D2	D1
SCE-84XM7818U	D7	D2	D1
SCE-90XM7824U	D7	D2	D1
SCE-72XM3EW18U	D7	D2	D1
SCE-84XM3EW18U	D7	D2	D1
SCE-84XM4EW18U	D7	D2	D1
SCE-90XM4EW18U	D7	D2	D1
SCE-84XM5EW18U	D7	D2	D1
SCE-60SA3812A24LPPL	D2	N/A	N/A
SCE-60XEL3712ALP4	D2	N/A	N/A

Handle / Operator	Cutout Detail
<b>C361H1</b>	<b>D1</b>
<b>C361H2</b>	<b>D1</b>
<b>C361H3</b>	<b>D1</b>
<b>C361H4</b>	<b>D1</b>
<b>Flex Shaft CH</b>	<b>D1</b>
<b>SM250</b>	<b>D9</b>
<b>SM150</b>	<b>D10</b>

