## **SCE-HS2S HOLE SEAL**



For Use On Enclosures Rated Type 1, 3, 3R, 3S, 4, 4X & 12



Remove protective backing from the gasket prior to installation.

2.00"

2.00"

Hole Seal Cutout Detail

Sealing surface of enclosure to be cleaned thoroughly with a 50/50 isopropyl (rubbing alcohol) water mixture, or similar cleaning solvent and wiped dry. Apply firm pressure to the entire bond line. Min. dwell time of 72 hours for full adhesion.