



Your Enclosure Source®

IMPORTANT!

USE YOUR SMARTPHONE TO SCAN OUR MOST POPULAR INSTRUCTIONS




ENCLOSURE DESIGN
CONSIDERATIONS



GENERAL ACCESSORIES



TECHNICAL INFORMATION



EASY SCAN



DISCONNECT SELECTION



MATERIAL SPECIFICATIONS



IMS OPTIONS



COATING & GASKET PERFORMANCE
CHARACTERISTICS



FOR DETAILED INSTALLATION INSTRUCTIONS OR TECHNICAL INFORMATION VISIT OUR WEBSITE AT WWW.SAGINAWCONTROL.COM 

GO DIRECTLY TO THE INSTALLATION MANUAL OR TECHNICAL INFORMATION PAGE FROM THE SCE HOME PAGE -OR- SEARCH BY PART NUMBER TO FIND LINKS TO PART-SPECIFIC INFORMATION

THERMAL MANAGEMENT



**INDUSTRY STANDARDS
RATINGS REFERENCES**



MOUNTING OPTIONS



LITERATURE




FREE-STANDING OPTIONS



**MECHANICAL &
ELECTRICAL INTERLOCK**



SERVICE



EASY SCAN



FOR DETAILED INSTALLATION INSTRUCTIONS OR TECHNICAL INFORMATION VISIT OUR WEBSITE AT WWW.SAGINAWCONTROL.COM
GO DIRECTLY TO THE INSTALLATION MANUAL OR TECHNICAL INFORMATION PAGE FROM THE SCE HOME PAGE -OR- SEARCH BY PART NUMBER TO FIND LINKS TO PART-SPECIFIC INFORMATION





Your Enclosure Source®

Type 3R ADDITIONAL INSTRUCTIONS

Multi-listed enclosures require drainage to be added to maintain Type 3R requirement.

- Type 3R, 12
- Type 3R, 4, 12
- Type 3R, 4, 4X & 12



Your Enclosure Source®

Type 3R ADDITIONAL INSTRUCTIONS

To maintain 3R listing, drainage is required. Install equally rated drainage device or drill a 1/8 to 1/4 inch hole in the bottom center of the enclosure, approximately 1 inch from the right, and 1 inch from the left for drainage, use listed rain-tight or wet location hubs. Drip shield over the door is recommended for all outdoor applications.